

**Panasonic JU-475-2 - Jumper settings**

I have gathered the following information to the best of my knowledge and belief. However, errors cannot be excluded. The use of this information is always at the user's own risk!

my system IBM 5170 motherboard type 3
controller HDC/FDC: Adaptec AHA-1542B with DP8473V

JUMPER	DESCRIPTION	SETTING
TM	Terminator	ON
DS1	Drive selected as DRIVE 1	OFF
DS2	Drive selected as DRIVE 2	ON
DS3	Drive selected as DRIVE 3	OFF
DS4	Drive selected as DRIVE 4	OFF
DS	Selection of a drive in a multidrive system enabled	ON
MX	Drive selected permanently	OFF
AT	Drive for use in the system enabled	ON
AX	Stores the Drive Select signal	OFF
RDY	Standard Ready signal	OFF
LR	Stores the Ready signal	OFF
DC	Stores door closure	ON
DS	Door open	OFF
BX	Double speed	OFF
CX	Single speed	ON
IRD	Internal Ready signal	OFF
SP	Step Disk Change	ON
DX	Index Disk Change	OFF
DO	Disk Change drive selection	OFF
UA	Front LED controlled by the Ready signal	OFF
DA	Front LED controlled by the Drive Select signal	ON
OA	Front LED controlled by the Ready or Drive Select signal	OFF
HA	Front LED controlled by the Ready and Drive Select signals	OFF
MM	Motor drive enabled by the Motor On signal	ON
MB	Motor drive enabled by the Drive Select signal	OFF

settings DS2, DS, AT, DC, CX, SP, DA, MM

